

Display type: Fujitsu FPF42C10660UB-01
 Cable no.: Not available
 System: 686LCD
 Display driver: 854 x 480, PLASMA, FUJITSU, FPF42C10660UB-01
 Status: Verified

| Display (68-pole conn.) | | Cable | JPLCD connector | | Remarks |
|-------------------------|----------|----------|-----------------|----------|---------|
| Pin no. | Function | Wire no. | Pin | Function | |
| 1 | DATA-R7 | 1 | 49 | P23 | |
| 2 | S.GND | 2 | * | GND | |
| 3 | DATA-R6 | 3 | 48 | P22 | |
| 4 | S.GND | 4 | * | GND | |
| 5 | DATA-R5 | 5 | 47 | P21 | |
| 6 | S.GND | 6 | * | GND | |
| 7 | DATA-R4 | 7 | 46 | P20 | |
| 8 | S.GND | 8 | * | GND | |
| 9 | DATA-R3 | 9 | 44 | P19 | |
| 10 | S.GND | 10 | * | GND | |
| 11 | DATA-R2 | 11 | 43 | P18 | |
| 12 | S.GND | 12 | * | GND | |
| 13 | DATA-R1 | 13 | 42 | P17 | |
| 14 | S.GND | 14 | * | GND | |
| 15 | DATA-R0 | 15 | 41 | P16 | |
| 16 | S.GND | 16 | * | GND | |
| 17 | DATA-G7 | 17 | 37 | P15 | |
| 18 | S.GND | 18 | * | GND | |
| 19 | DATA-G6 | 19 | 36 | P14 | |
| 20 | S.GND | 20 | * | GND | |
| 21 | DATA-G5 | 21 | 34 | P13 | |
| 22 | S.GND | 22 | * | GND | |
| 23 | DATA-G4 | 23 | 33 | P12 | |
| 24 | S.GND | 24 | * | GND | |
| 25 | DATA-G3 | 25 | 31 | P11 | |
| 26 | S.GND | 26 | * | GND | |
| 27 | DATA-G2 | 27 | 30 | P10 | |
| 28 | S.GND | 28 | * | GND | |
| 29 | DATA-G1 | 29 | 28 | P9 | |
| 30 | S.GND | 30 | * | GND | |
| 31 | DATA-G0 | 31 | 27 | P8 | |
| 32 | S.GND | 32 | * | GND | |
| 33 | N.C. | 33 | - | - | |
| 34 | N.C. | 34 | - | - | |
| 35 | DATA-B7 | 35 | 25 | P7 | |
| 36 | S.GND | 36 | * | GND | |
| 37 | DATA-B6 | 37 | 24 | P6 | |

| | | | | | |
|----|---------|----|----|--------|----------------------------------|
| 38 | S.GND | 38 | * | GND | |
| 39 | DATA-B5 | 39 | 22 | P5 | |
| 40 | S.GND | 40 | * | GND | |
| 41 | DATA-B4 | 41 | 21 | P4 | |
| 42 | S.GND | 42 | * | GND | |
| 43 | DATA-B3 | 43 | 19 | P3 | |
| 44 | S.GND | 44 | * | GND | |
| 45 | DATA-B2 | 45 | 18 | P2 | |
| 46 | S.GND | 46 | * | GND | |
| 47 | DATA-B1 | 47 | 16 | P1 | |
| 48 | S.GND | 48 | * | GND | |
| 49 | DATA-B0 | 49 | 15 | P0 | |
| 50 | S.GND | 50 | * | GND | |
| 51 | /VSYNC | 51 | 11 | FLM | |
| 52 | S.GND | 52 | 9 | GND | |
| 53 | /HSYNC | 53 | 10 | LP | |
| 54 | S.GND | 54 | 6 | GND | |
| 55 | /BLANK | 55 | 7 | M | |
| 56 | S.GND | 56 | 12 | GND | |
| 57 | /DCLK | 57 | 13 | SHFCLK | |
| 58 | S.GND | 58 | 14 | GND | |
| 59 | N.C. | 59 | - | - | |
| 60 | S.GND | 60 | * | GND | |
| 61 | DISPEN | 61 | 4 | ENVCC | |
| 62 | S.GND | 62 | * | GND | |
| 63 | N.C. | 63 | - | - | |
| 64 | B-CNT0 | 64 | - | - | Connect to 5kΩ pot. |
| 65 | B-CNT1 | 65 | - | - | Connect to 5kΩ pot. |
| 66 | B-CNT2 | 66 | - | - | Connect to 5kΩ pot. (Center pin) |
| 67 | HQEN | 67 | - | - | +5V = High q. (otherwise GND) |
| 68 | N.C. | 68 | - | - | |

* pin 17, 20, 23, 26, 29, 32 35, 38, 45 and 50