

Display type: FPD LDE052T
 Cable no.: N/A
 System: 586LCD/GXm
 Display driver: LDE052T
 Status: Verified

Display (26-pole conn.)		JPLCD connector		Remarks
Pin no.	Function	Pin	Function	
1	GND	12	GND	
2	CLK	13	SHFCLK	
3	Vdd	1,2	LCDVCC	
4	FLM	11	FLM	
5	INTF	9	GND	INTF = 0 LP Int. INTF = 1 Data Enable Int.
6	ENAB	7	DE/M	
7	VRV	6	GND	VRV = 0 U/D scan VRV = 1 D/U scan
8	LP	10	LP	
9	GND	14	GND	
10	Display_On	8	ENBKL	
11	HRV	17	GND	HRV = 0 L/R Scan HRV = 1 R/L Scan
12	GND	45	GND	
13	R0	46	P20	
14	R1	47	P21	
15	R2	48	P22	
16	R3	49	P23	
17	GND	20	GND	
18	B0	21	P4	
19	B1	22	P5	
20	B2	24	P6	
21	B3	25	P7	
22	GND	32	GND	
23	G0	33	P12	
24	G1	34	P13	
25	G2	36	P14	
26	G3	37	P15	

Inverter Connector		JPLCD connector		Remarks
Pin no.	Function	Pin	Function	
1	+12 V	99,100	+12 V	
2	GND	92	GND	
8	Vdim	39	BlkReg	0-5 Volt, 64 steps, Controlled via BIOS
9	GND	87	GND	GND for brightness control