

Display type: Torisan LM-FE53-22NTK
 Inverter type: Not available
 Cable type: 40860021
 System: 486-586LCD/S, FPUM-3 and AC-2
 Display driver: KYO KCB8060ESTT-X1
 Status: Not verified

Display	CN1	CPU (JPLCD)		Remarks
Function	Pin no.	Pin no.	Function	
FLM	1	11	VSYNC	
M	2	7	M	
/DISP OFF	3	4	ENVCC	
CL1	4	10	HSYNC	
VSS	5	12	GND	
CL2	6	13	SHFCLK	
VSS	7	14	GND	
UD0	8	36	P14	Display data for upper column drive
UD1	9	33	P12	Display data for upper column drive
UD2	10	30	P10	Display data for upper column drive
UD3	11	27	P8	Display data for upper column drive
UD4	12	24	P6	Display data for upper column drive
UD5	13	21	P4	Display data for upper column drive
UD6	14	18	P2	Display data for upper column drive
UD7	15	15	P0	Display data for upper column drive

Display	CN2	CPU (JPLCD)		Remarks
Function	Pin no.	Pin no.	Function	
LD0	1	37	P15	Display data for lower column drive
LD1	2	34	P13	Display data for lower column drive
LD2	3	31	P11	Display data for lower column drive
LD3	4	28	P9	Display data for lower column drive
LD4	5	25	P7	Display data for lower column drive
LD5	6	22	P5	Display data for lower column drive
LD6	7	19	P3	Display data for lower column drive
LD7	8	16	P1	Display data for lower column drive
VDD	9	1	VCC	
VSS	10	6	GND	
VSS	11	9	GND	
VDD	12	2	VCC	
VDD	13	2	VCC	
VCON	14	40	VEE	LCD adjust voltage (0.8V to 2.8V)